



DAY 1

1. Process begins at store closing.
2. Upper Bay Area: Owner is responsible to remove all displays, POS terminals, shelving, water coolers, vending machines and anything else that is in direct contact with the floor. (Wall mounted shelving if it is 18" off the floor is acceptable to leave in place.)
3. If Office, Lobby, Restroom Area are to be done, owner is responsible to remove furniture, fixtures, disconnect and cover all office and computer equipment. If owner chooses to have material under the commode then owner will be responsible for it's removal and replacement, otherwise we will cut floor material up to the edge of the commode(s).
4. We will do diamond-wheel grinding or scarifying. The amount of time this takes varies depending on the size and condition of the existing floor.
5. We sweep and vacuum.
6. We apply a Portland cement based underlayment.
7. We allow this to dry overnight.
8. Arrangements will need to be made to secure the store at night when this process is complete.

DAY 2

1. Next morning we will begin installation phase at 7:00 a. m.
2. Arrangements will need to be made to have the store open.
3. The store will need to be closed all day.
2. Sanding, vacuuming and finishing the underlayment occurs.
4. We cut and dry lay the entire store, we fold back material and apply epoxy adhesive - then we install rubber tile.
5. We roll floor with a roller and allow floor to dry overnight.
6. Arrangements need to be made to secure the store that night.

DAY 3

1. Next morning store is open for business. Owner is responsible to set store back up for business that day.
2. Allow floor to dry 72 hours before applying water or any cleaning fluids. Wipe up spills with a damp mop only.